



Manual to install rudder feed back in Jefa DU-LD-12



Unscrew 4pcs of screw.  
NB!! Do not dismount screw in the center, only 4pcs in edge




Use flat screwdriver or flat tool to pull housings apart



Pull out plastic plug to mount the cable screw



Mount the rudder feed back.  
NB!!! Do not use hammer on rudder feed back, only use hands



Assemble the cable screw to hold the cable for rudder feed back



Take gearwheel from top housing and mount it on the gearwheels on bottom housing



Assemble housings, and make sure that the gearwheels are fitting



Mount 4pcs of screw to assemble the drive unit



Pull drive arm out to stop



Push drive arm in to stop.  
Installation of the rudder feed back is done.