



Manual for mounting steering wheel on Hydraulic pedestal



Mount your steering wheel on the shaft's conus for the wheel. Make sure the keyway in the steering wheel hub is locked with the key in steering shaft.



Mount the special screw, which has both a M8 thread and a M10 thread. Use the M8 thread to screw into the steering shaft, 25Nm with a 24mm key



Screw your brake spinner hub on the M10 thread turning clockwise with your hands only.



To dismount the steering wheel on a hydraulic steering system, first remove the brake spinner hub by turning it counterclockwise



Dismount the special screw with a 24mm key, and pull of the steering wheel

NB: It's very important that you don't tighten the special screw too much when mounting to the shaft, since this can make the M8 thread on the special screw break.